

PARTS LIST:

- Can (1)
- Post (1)
- Dispenser (1)
- Can Bracket (2)
- Sign (1)
- Dispenser Keys (2) *INSIDE Dispenser
- 400 Bags
- 50 Can Liners
- Hardware Pack (1)



CAN (1)



DISPENSER (1)



HARDWARE (1)



CAN BRACKET (2)



SIGN(1)



400 BAGS



50 CAN LINERS



POST* (1)

*2 Post Sections 47 1/2" Each

NUTS & BOLTS LIST:

- 3" Bolt (7)
- A** 
- 3/4" Bolt (4)
- B** 
- Flat Washers (11)
- C** 
- Split-Lock Washer (11)
- D** 
- Hex Nuts (7)
- E** 

ASSEMBLY INSTRUCTIONS

1. ALWAYS CHECK for buried services (electric, water, gas, phone, cable) before digging. Dig a post hole 14" deep. Pour in concrete.
2. ASSEMBLE THE 2-PIECE POST securely and set and level the post. The thinner post section should be inserted 4" into the larger width section. Then use one 3" bolt (A) to secure the 2 sections together. Allow cement to firmly set-up before attaching can and dispenser to post.
3. POSITION CAN 5" above ground and secure to post using the 2 brackets provided. Bolt through bracket holes directly into can (4 B, D only). Be sure to use the correct bracket for the thicker post section and the other for the thinner post section. Bolt through bracket/post cross section (2 A, C, D, E).
4. INSTALL THE DISPENSER 10" above the top of the Can. Be sure to place washers (C) on the bolts as you bolt from the inside of the dispenser through to the post.
5. ATTACH SIGN to top of post with 2 bolts, nuts and washers (use 2 B, C, D, E).
6. FILL DISPENSER with bags – Install Can Liner.

PLEASE BE SURE TO TIGHTEN ALL NUTS AND BOLTS SECURELY

